



Instructions for Use of Cryptomats



Table of Contents

Buy Coins	4
Withdraw Cash	8
Redeem the Cash.....	11



CRYPTOMAT

support@cryptomat.ge

+995 322 880 770

Cryptomat ATMs support two-way operations: buying and selling/withdrawing coins (Bitcoin (BTC), Bitcoin Cash (BCH), Litecoin (LTC) and Ethereum (ETH)) for cash.



დაგვიკავშირდით
ხელფონის ნომერზე
+995 706 770 527


CRYPTOMAT



დააჭირეთ მონეტორს

**იყიდეთ და გაყიდეთ
ბიტკოინი აქ**

გვადლოთ, რომ სარგებლოდ ჩვენი კონიპობებით


დახმარება გჭირდებათ?
support@cryptomat.ge
www.cryptomat.ge

Touch the screen to start the transaction;


Buy Coins



From the start menu select → Buy Coins;



Select the coin you want to buy: Bitcoin, Litecoin, Ethereum or Bitcoin Cash;



Press → Scan Wallet QR Code

To scan the QR code of your wallet address, open your mobile application (ex: Blockchain) and press → Request;



Now, scan your wallet QR code (barcode) from your mobile application;


Note: For the best scan hold your QR code 10-15 centimeters away from the scanner;



Insert cash bills into the bill acceptor¹;

Please be noted that minimum purchase amount is **10 GEL**.

Click → Finish;



Take a receipt;


Your transaction has been completed!

¹ *Note:* How much of BTC, BCH, LTC, ETH you can buy for the cash inserted, is shown on the screen; Additionally, on the upper right corner of Cryptomat ATMs BTC, BCH, LTC, ETH exchange rates are indicated (green-colored fonts).


Withdraw Cash




To sell your coins for cash/withdraw in GEL, choose → Withdraw Cash from the start menu;




Select the coin you want to cash out: Bitcoin, Litecoin, Ethereum or Bitcoin Cash;



Choose the amount you want to withdraw;



Barcode/QR code and the address (green-colored fonts) – where your coins should be sent – appears on the screen;

To continue the transaction, open your mobile application (ex: Blockchain) and press  Send;


In order to insert the indicated address into the field “To: Enter Bitcoin/litecoin address” press on the Barcode symbol on the upper right corner of your mobile phone;

Now scan the barcode/QR code from the Cryptomat ATM screen;

Check if those two addresses (on the Cryptomat ATM screen and in your mobile application) match each other;

In your mobile application confirm sending the coins to the indicated address;


After confirmation, take the receipt with the Redemption Code from the Cryptomat ATM and wait for couple of minutes (on average from 30 minutes to 2 hours) until your transaction is confirmed on the Blockchain Network;




Redeem the Cash



After that your transaction is confirmed on Blockchain Network, go back to the Cryptomat ATM and select  Redeem, from the start menu;



Enter Cash Redemption Code in the corresponding field;

Click  Finish Withdrawal;



Indicate if you want to receive a receipt;

Transaction was successfully completed!

Take your money [and receipt]!